NEXUS 21

Hex Codes for Nexus 21 IR Remote Control

These codes describe the infrared signals sent by the remote, and may be used for programming the TV lift commands into AV control systems and universal remote controls.

EXTEND: 0000 006D 0000 000C 000C 0115 000C 0115 000C 0115 000C 00B7 000C 0115 000C 00B7 000C 00B7 000C 00B7 000C 0115 000C 0115 000C 0115 000C 0255

STOP [no button on remote for this code, but this is a valid function, see next line] (same as pressing the "UP" button when the lift is going down OR pressing "DOWN" when it's going up) 0000 006D 0000 000C 000E 0115 000E 00B5 000E 0115 000E 00B5 000E 0115 000E 00B5 000E 00B5 000E 00B5 000E 0115 000E 0115 000E 0115 000E 0240

RETRACT: 0000 006D 0000 000C 000E 0115 000E 0115 000E 0115 000E 00B5 000E 0115 000E 00B5 000E 00B5 000E 0115 000E 00B5 000E 00B5 000E 00B5 000E 0240

Infrared

The following table lists the pronto hex codes for Infra-red control for the APEX Motorized Wall Mount.

Description	Code
MEMORY POSITION 1	0000 006c 0022 0002 0158 00ab 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 0015 0016 0015 0016 0015 0016 003f 0016 0015 0016 0015 0016 0015 0016 0015 0016 003f 0016 003f 0016 003f 0016 0015 0016 003f 0016 05e6 0157 0055 0016 0e38
MEMORY POSITION 2	0000 006c 0022 0002 0158 00ab 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 0015 0016 003f 0016 0015 0016 003f 0016 003f 0016 0015 0016 003f 0016 0015 0016 003f 0016 0015 0016 003f 0016 0015 0016 0015 0016 003f 0016 0015 0016 003f 0016 05e6 0157 0055 0016 0e3a
MEMORY POSITION 3	0000 006c 0022 0002 0158 00ab 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 0015 0016 0015 0016 003f 0016 003f 0016 0015 0016 0015 0016 0015 0016 0015 0016 003f 0016 003f 0016 0015 0016 0015 0016 003f 0016 003f 0016 003f 0016 05e5 0157 0055 0016 0e37
HOME	0000 006c 0022 0002 0158 00ab 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 0015 0016 003f 0016 0015 0016 0015 0016 0015 0016 003f 0016 0015 0016 0015 0016 003f 0016 0015 0016 003f 0016 003f 0016 003f 0016 0015 0016 003f 0016 05e6 0157 0055 0016 0e3a
STOP	0000 006c 0022 0002 0158 00ab 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 0015 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 003f 0016 0015 0016 0015 0016 003f 0016 0015 0016 0015 0016 0015 0016 0015 0016 003f 0016 003f 0016 0015 0016 003f 0016 003f 0016 003f 0016 003f 0016 05e6 0157 0055 0016 0e38

COPYRIGHT NEXUS 21 2019 – ALL RIGHTS RESERVED